


# QUICK SETUP

1 Connect the powerhead to the ratchet link.



a Push the ratchet mechanism all the way in (if needed).




b Hook powerhead to link.





c Secure tool with link pin.

2 Make sure your hoses are free of any defects. Connect hose to the corresponding couplers on the pump and tool.



3 Cycle the tool.




click  
→  
click



Press ON.  
Click.  
Release.  
Click.

4 NOTE: Easy to remember tool position for tightening and loosening.

Tightening.




Loosening.



5 Use the pressure/torque conversion chart to set the psi for the torque value you need. NOTE: Only use the chart that corresponds to the tool you are using.

RTX-4	
Pressure (PSI)	Torque (FT-LBS)
100	100
110	110
120	120
130	130
140	140
150	150
160	160
170	170
180	180
190	190
200	200
210	210
220	220
230	230
240	240
250	250
260	260
270	270
280	280
290	290
300	300
310	310
320	320
330	330
340	340
350	350
360	360
370	370
380	380
390	390
400	400
410	410
420	420
430	430
440	440
450	450
460	460
470	470
480	480
490	490
500	500
510	510
520	520
530	530
540	540
550	550
560	560
570	570
580	580
590	590
600	600
610	610
620	620
630	630
640	640
650	650
660	660
670	670
680	680
690	690
700	700
710	710
720	720
730	730
740	740
750	750
760	760
770	770
780	780
790	790
800	800
810	810
820	820
830	830
840	840
850	850
860	860
870	870
880	880
890	890
900	900
910	910
920	920
930	930
940	940
950	950
960	960
970	970
980	980
990	990
1000	1000



Turn the T-handle to the right to set the pressure.

## WARNING:

NEVER PLACE HANDS NEAR ACTION OR REACTION POINTS.  
ALWAYS WEAR HARD HAT, SAFETY GLOVES, GOGGLES, STEELTOE BOOTS AND EARPLUGS  
THE PUMP AND THE TOOL SHOULD BE OPERATED BY THE SAME PERSON.